



INSTRUCTIONS FOR SETUP

To contact NEMO Customer Service
Email: journey@nemoequipment.com
Phone: 800-997-9301





1 Attach Hammock Anchors

Secure webbing tree straps around at least 10" diameter, sturdy trees, a minimum of 13' apart. Girth hitch trees by passing anchor strap end through strap loop, then attaching to hammock buckles, located at each end of the hammock.




2 Tension Hammock

Pull the loose end of the tree strap at the buckle to adjust hammock tension. Weighted sleep surface should not exceed 18" above ground. To release tension from the buckle, pull the webbing loop in the direction of the hammock.



3 Anchor Hammock

Stake out the two hammock guy lines using the cord locks to adjust tension. Guy lines should be perpendicular to the hammock and at a 45 degree downward angle.



4 Attach Rain Fly

If the weather necessitates, affix the rain fly above the hammock using the 6 guy lines. Inspect the setup to make sure the hammock and tree strap buckles are covered by the fly to prevent water from migrating into the hammock. Be sure to leave an air space between the fly and hammock canopy.



5 Maximize Comfort

Position your head at the correct end of the hammock and lay on a diagonal for the flattest sleeping position. Utilize the gear shelf to keep the sleep surface clear. Be sure to use an appropriate pad or hanging quilt for underneath insulation in colder weather.

©2018 NEMO Equipment, Inc.



Remember to leave no trace. Before leaving your campsite, take a thorough look around making sure you have not left anything behind, out of place, or damaged.

TETRAPOD™